


# Rear Suspension

## Torque Specification



### CAUTION:

- Replace self-locking nuts after disassembly.
- Replace self-locking bolts if you can easily thread a nut past their nylon locking inserts.



**CAUTION:** The vehicle should be on the ground before any bolts or nuts connected to rubber mounts or bushings are tightened.