

Clutch

Illustrated Index

NOTE: Whenever the transmission is removed, release bearing sliding surface should be cleaned and greased.

