

# Trunk

## Lid Replacement/Adjustment

1. Remove the clips, then remove the trunk lid inner trim panel.
2. Pull the harness out of the trunk lid.

**NOTE:** Before pulling out the wire harness, tie a string to the end of it so you can pull it back in when the trunk lid is reinstalled.

3. Remove the trunk lid hinge bolts, then lift off the lid.
4. Remove the torsion bar using a release tool.
5. Remove the rear shelf (page 14-42).
6. Remove the hinge bracket mounting bolts, then remove the hinges from the trunk.
7. Assemble in the reverse order.

**NOTE:** Before tightening the hinge bolts, check the adjustments shown below:

