


Taillight Assembly




Replacement

1. Open the trunk lid and the maintenance cover of the taillight.
2. Turn the socket 45° counterclockwise to remove it from behind the taillight assembly.



3. Turn the bulb 45° counterclockwise to remove it from the socket.

4. Remove the rear trim panel.
5. Disconnect the 8-P connector from behind the taillight.
6. Remove the 6 mount nuts and the taillight assembly.



7. Inspect the gasket; replace if it is distorted or overly compressed.