







# Function Control Panel

## Function Control Switch Test



1. Disconnect the 16P connector from the heater control.
2. Check for continuity between the terminals according to the table.

Terminal	7	1	13	14	15	16
Position						
					○	○
				○		○
			○			○
		○				○
	○					○



## Recirculation Control Switch Test

1. Disconnect the 16P connector from the heater control.
2. Check for continuity between the terminals according to the table.

Terminal	12	11	3
Position			
	○		○
		○	○

