



## Opener and Latch Replacement

1. Remove the kick panel (page 14-42).
2. Remove the bolts, then remove the hood opener and disconnect the opener cables.
3. Remove the 2 bolts from each hood lock, then remove the hood locks and disconnect the opener cables.
4. Remove the inner fender, then pull out the opener cables.

NOTE: Before pulling out the opener cables, tie strings to both ends so you can pull them back in later.

5. Remove the front grille and 2 condenser mount bolts.
6. Pull the condenser forward, then remove the hood latch mount bolts and nut, and the hood latch.

NOTE: Do not drop bolts and nut.

