


Headlights

Adjustment

NOTE: Adjust the headlights to local requirements.




Replacement


CAUTION:

- Halogen headlights can become very hot in use; do not touch them or the attaching hardware immediately after they have been turned off.
- Do not try to replace or clean the headlights with the lights on.

1. Disconnect the 3-P connector from behind the bulb.
2. Remove the rubber boot from behind the light by pulling the tab.
3. Unhook the retaining spring and remove the bulb.



4. Remove the front grille, the front bumper and the front marker light.
5. Remove the 4 mount bolts and 2 screws, then remove the unit.



6. After installing the unit, adjust the headlights to local requirements.