




# Parking Brake Stopper

## Inspection/Adjustment

1. Set the parking shift arm in PARKING position.
2. Measure the distance between the outer face of the parking pawl shaft and outer face of the parking shift arm roller pin.

Distance: 30.5–31.5 mm (1.201–1.240 in.)



3. If the distance is out of the specification, select the appropriate parking brake stopper using the table below, and install it on the parking shift arm.

No.	PART NUMBER
1	24537-PA9-003
2	24538-PA9-003
3	24539-PA9-003