


Electrical Component Replacement

Ambient Temperature Sensor

1. Remove the front grille (See Section 14).
2. Remove the screw, disconnect the wire harness and then remove the ambient temperature sensor.



NOTE: Be careful not to damage the front grille and front bumper.


Installation:

Install the ambient temperature sensor in the reverse order of removal.

Sunlight Sensor

Removal:

1. Remove the dashboard (See section 14).
2. Unscrew the sunlight sensor from the dashboard and disconnect the wire harness.



NOTE: Be careful not to damage the dashboard.

Installation:

Install the Sunlight Sensor in the reverse order of removal.