


Hub Bearing Unit

Replacement

1. Raise the rear of car and support it with safety stands in proper locations.
2. Remove the rear wheel.
3. Remove the rear caliper and brake disc.
4. Remove the hub unit cap, then pry the spindle nut lock tab away from the spindle and loosen the nut.
5. Remove the hub bearing unit.



6. Install in reverse order of removal.
Also, tighten the new spindle nut to specified torque before staking the nut.

Upper Arm

Ball Joint Removal

1. Remove the upper arm ball joint cap.
2. Remove the cotter pin and ball joint nut.
3. Position the bearing puller between the knuckle and upper arm as shown below, and remove the knuckle from the upper arm.

