




Inspection

CAUTION: The crankshaft should rotate clockwise when viewed from the pulley side.

NOTE:

- Replace belt if oil soaked.
- Quickly remove any oil or solvent that gets on the belt.

Inspect this area for wear.



Tension Adjustment

CAUTION: Always adjust timing belt tension with the engine cold.

NOTE: Tensioner is spring-loaded to apply proper tension to the belt automatically after making the following adjustment:

- The crankshaft should rotate clockwise when viewed from the pulley side.

1. Set the No. 1 piston at TDC compression stroke.
2. Rotate the crankshaft clockwise 9-teeth on camshaft pulley (The blue mark on crankshaft pulley should match the pointer on lower cover).
3. Loosen the adjusting bolt to create tension on timing belt.
4. Tighten the adjusting bolt.

