



## **BRAKE LIGHT SWITCH**

Pedal Height Adjustment, page 13-4

## **PARKING BRAKE**

Adjustment, page 13-4

Disassembly and Reassembly, page 13-28

## **BRAKE HOSES/PIPES**

Inspection, page 13-5

Connections, pages 13-7 and 13-6

## **BRAKE BOOSTER**

Test, page 13-9

Pushrod Clearance Adjustment, page 13-10

## **REAR BRAKE**

Index/Inspection, page 13-18

Brake Pad Disc Inspection Replacement,  
page 13-19

Brake Caliper Disassembly, page 13-21

Brake Caliper Reassembly, page 13-24

## **MASTER CYLINDER**

Overhaul/Inspection, page 13-9

Disassembly, page 13-10

Reassembly, page 13-11

## **MODULATOR**

Index/Inspection, page 13-55

Brake Fluid Praining, page 13-56

### **Solenoids**

Leak Test, page 13-56

Removal, page 13-57

Inspection, page 13-58

Reassembly, page 13-58


### **Piston**

Removal, page 13-59

Installation, page 13-60

## **CONTROL UNIT**

Replacement, page 13-67



## **POWER UNIT**

Index/Inspection, page 13-61

Disassembly, page 13-62

Reassembly, page 13-63

## **FRONT SPEED SENSOR**

Inspection, page 13-68

Replacement, page 13-69

## **REAR SPEED SENSOR**

Inspection, page 13-68

Replacement, page 13-69

## **FRONT BRAKE**

Index/Inspection, page 13-13

Brake Pad Inspection/Replacement, page 13-14

Brake Caliper Disassembly, page 13-15

Brake Caliper Reassembly, page 13-16

Brake Disc Inspection, page 13-17

## **ACCUMULATOR**

Index/Inspection, page 13-64

Disassembly/Reassembly, page 13-65

Accumulator Disposal, page 13-65