

Evaporator

Replacement




SRS wire harness is routed near the evaporator.

⚠ WARNING All SRS wire harness and connectors are colored yellow. Do not use electrical test equipment on these circuit.


CAUTION: Be careful not to damage SRS wire harness when servicing the evaporator.

1. Disconnect the battery negative terminal.
2. Discharge the refrigerant.
3. Disconnect the receiver line and suction hose from the evaporator.

CAUTION: Cap the open fittings immediately to keep moisture out of the system.




4. Remove the 5 screws, then remove the glove box lower cover and glove box.
5. Remove the 4 screws, then remove the glove box frame and side duct.
6. Disconnect the wire harness from the thermostat switch connector.



THERMOSTAT
SWITCH
CONNECTOR

7. Remove the 4 tapping screws and 3 mounting bolts.



8. Pull the evaporator away from the body.
9. Install in the reverse order of removal, and:
 - Apply a sealant to the grommets.
 - Make sure that there is no air leakage.
10. Charge the system and test performance.