


# Engine Block

**Illustrated Index ..... 5-54**  
**Main Bearings and Rod Bearings ..... 5-56**  
**Pistons and Crankshaft ..... 5-57**  
**Cylinder Block ..... 5-59**  
**Piston Pins ..... 5-61**  
**Piston Rings ..... 5-63**  
**Oil Seal ..... 5-65**  
**Crankshaft Installation ..... 5-66**



## Special Tools

| Ref. No. | Tool Number    | Description                      | Q'ty | Remarks                           |
|----------|----------------|----------------------------------|------|-----------------------------------|
| ①        | 07973-6570002  | Piston Pin Dis/Assembly Tool Set | 1    |                                   |
| ①-1      | 07973-6570500  | Piston Base                      | 1    | Component Tool                    |
| ①-2      | 07973-6570600  | Piston Base Spring               | 1    |                                   |
| ②        | *07HAF-PL20101 | Piston Base Head                 | 1    |                                   |
| ③        | 07GAF-PH70100  | Pilot Collar                     | 1    |                                   |
| ④        | 07GAF-PH60300  | Piston Pin Base Insert           | 1    | 07973-PE00301 may also be used.   |
| ⑤        | 07973-PE00302  | Adjustable Piston Pin Driver     | 1    |                                   |
| ⑥        | 07948-SB00101  | Seal Driver Attachment           | 1    | Crankshaft oil seal (clutch side) |
| ⑦        | 07749-0010000  | Driver                           | 1    | Crankshaft oil seal (pulley side) |
| ⑧        | 07GAD-PH70200  | Oil Seal Driver                  | 1    |                                   |

\*New Tool

