

Fuse Box/Fuse Holder


Removal/Installation

CAUTION:


- Be sure to install the SRS wiring so that it is not pinched or interfering with other car parts.
- Always keep the short connector on the airbag connector when the harness is disconnected.

Removal:

1. Disconnect both the negative cable and positive cable from the battery.
2. Remove the maintenance lid A below the airbag, then remove the short connector.





3. Disconnect the connector between the airbag and cable reel.
4. Connect the short connector to the airbag side of the connector.



5. Remove the dashboard lower panel.
6. Remove the fuse box and fuse holder mounting bolt.
7. Disconnect the fuse box and fuse holder connectors.

NOTE: The SRS main harness connector is double locked. To remove it, first lift the connector lid with a thin screwdriver, then press the connector tab down and pull the connector out.


8. Pull out the fuse box and fuse holder.





Installation:

1. Install the fuse box and fuse holder.




SRS FUSE FUSE HOLDER

2. Connect the connectors to the fuse box and fuse holder.

NOTE: To reinstall the SRS main harness connector, push it into position until it clicks, then close the connector lid.

3. Install the dashboard lower panel.
4. Disconnect the short connector from the airbag.



5. Connect the airbag 2-P connector and cable reel 2-P connector.
6. Attach the short connector to the lid A and attach to the steering wheel.
7. Connect both the negative cable and positive cable to the battery.
8. After installing the airbag assembly, confirm proper system operation:
 - Turn on the ignition to II; the instrument panel SRS light should go on for about 8 seconds and then go off.
 - Confirm operation of the lighting and wiper switches.
 - Confirm operation of the air conditioner, heater, radio/cassette player and brake lights.
 - Confirm operation of the cruise control set/resume switch.