


Pulsers/Sensors


Front Sensor Replacement

NOTE:

- Be careful when installing the sensors to avoid twisting the wires using the white line on the wires as guide.
- After sensor replacement confirm proper operation.



6 x 1.0 mm
10 N·m
(1.0 kg-m, 7 lb-ft)



SRS wire harness is routed near the ALB front speed sensors.



WARNING All SRS wire harness and connectors are colored yellow. Do not use electrical test equipment on these circuit.

CAUTION: Be careful not to damage SRS wire harness when servicing the ALB front speed sensors.

Rear Sensor Replacement

NOTE:

- Be careful when installing the sensors to avoid twisting the wires using the white line on the wires as a guide.
- After sensor replacement, confirm proper operation.

6 x 1.0 mm
10 N·m (1.0 kg-m, 7 lb-ft)

