


Washer Level Warning System



Console Switch Replacement

1. Remove the front console and the center instrument panel, then disconnect the 10-P and 2-P connectors from the console switch.
2. Remove the 2 bolts to replace the console switch.




4. Position the switch slider to "Neutral" as shown above.
5. Shift the select lever to "Neutral", then slip the console switch into position.
6. Tighten the switch with the 2 bolts.

Warning Light Test

NOTE: Refer to page 16-76 for wiring description of the washer level warning circuit.

1. Turn the ignition switch on.
If the washer level warning light comes on, check the washer fluid level, and add washer fluid if necessary.
2. Remove the front bumper, then disconnect the 2-P connector from the washer fluid level switch. Connect the A (GRN/BLK) terminal to the B (BLK) terminal with a jumper wire. The warning light should come on as the ignition switch is turned on.



- If the light comes on, the problem is the washer fluid level switch.
- If the light does not come on, check for:
 - Poor ground (G201 or G701).
 - No power to the warning circuit.
 - An open in the GRN/BLK wire to the gauge assembly.
 - Bad bulb.
 - Faulty warning circuit.