


Headliner



Replacement

1. Remove:
 - Sunvisors and holders.
 - Rearview mirror and base (page 14-51).
 - Front pillar trim (page 14-42).
 - Quarter window trim panel (page 14-42).
 - Dome light.
 - Roof trim.
2. Remove the screws, then remove the coat hanger and grab handle.
3. Remove the mounting screws and the clips, then remove the headliner.



4. Assemble the headliner in the reverse order of disassembly.

NOTE:

- When inserting the headliner inside the passenger cabin, be careful not to fold or bend it. Also, be careful not to scratch the body.
- Check that the two sides of the headliner are securely attached to the trim.