




Front Cover Replacement


Front Seat Back:

1. Separate the seat cushion and back. (page 14-44).
2. Remove the springs and the clips.
3. Remove the upper and lower hooks, then remove the trim cover.



Front seat cushion:

4. Remove the screw, then remove the right and left corner brackets.
5. Remove the 4 clips, and front and rear trim cover first, then remove the right and left hooks.
6. Remove the 3 springs, then remove the trim cover.



NOTE: To prevent wrinkles when installing a seat cover, make sure the material is stretched evenly over the frame before securing all the clips.