


Supplemental Restraint System (SRS)

Front Sensors Removal


CAUTION:

- Do not damage the sensor wiring.
- Do not install used SRS parts from another car. When repairing: use only new SRS parts.
- Carefully inspect the front sensors for signs of being dropped or improperly handled, such as dents, cracks or deformation.

1. Disconnect both the negative cable and positive cable from the battery.
2. Remove the maintenance lid A below the airbag, then remove the short connector.




3. Disconnect the connector between the airbag and cable reel.
4. Connect the short connector to the airbag side of the connector.




5. Remove the left and right front inner fenders. From the left side, remove the resonator chamber, and from the right side remove the washer tank and receiver tank.

Left side:




Right side:







6. Pull back the carpeting and remove the PGM-FI ECU.



7. Unclip the sensor harness from the holders.



8. Disconnect the connectors from the SRS unit. The connectors are double-locked. To remove them first lift the connector lid with a thin screwdriver, then press the connector tab down and pull the connector out.



CAUTION:

- Avoid breaking the double-locked connectors.
- Do not disassemble or tamper.
- No serviceable parts inside.
- Store SRS parts in a clean dry area.

9. Remove the sensor mounting bolts, and remove the sensor. Disconnect the sensor harness from the clips.

