



Abbreviations

A/C	Air Conditioner
ALB	Anti Lock Brake
A/T	Automatic Transmission
ATF	Automatic Transmission Fluid
BAT	Battery
CATA	Catalytic Converter
EACV	Electronic Air Control Valve
ECU	Electronic Control Unit
EGR	Exhaust Gas Recirculation
EACV	Electronic Air Control Valve
EX	Exhaust
GND	Ground
IG	Ignition
IN	Intake
INT	Intermittent
L.	Left
LHD	Left Hand Drive
M/T	Manual Transmission
PCV VALVE	Positive Crankcase Ventilation Valve
PGM-FI	Programmed Fuel-Injection
P/S	Power Steering
R.	Right
RHD	Right Hand Drive
SOL. V	Solenoid Valve
SW	Switch
TA	Intake Air Temperature
TDC	Top Dead Center
TW	Coolant Temperature
P	<i>Packing Position</i>
R	<i>Reverse Position</i>
N	<i>Neutral Position</i>
D	<i>Drive Position</i>
S	<i>Sport Position</i>
2	<i>Fixed at 2nd Range</i>