




Troubleshooting Flow Chart — ECU

Check engine warning light isn't on for 2 seconds after ignition is first turned on.





(cont'd)

PGM-FI Control System

Troubleshooting Flow Chart — ECU (cont'd)


- Check engine warning light is on.
- Red LED doesn't blink.








(To page 6-27)



(From page 6-26)



Turn the ignition switch ON.



Substitute a known-good ECU and recheck. If symptom/indication goes away, replace the original ECU.