




Timing Belt

Illustrated Index

NOTE:

- Before removing, mark direction of rotation.
- Refer to base manual for:
 - positioning of the crank and pulley before installing the timing belt.
 - alternator belt adjustment.
 - power steering pump belt adjustment.
 - air conditioning compressor belt adjustment.



14 x 1.25 mm
170 N·m (17.0 kg-m, 123 lb-ft)
Apply engine oil to the
bolt threads.