



Component Testing

In-car Temperature Sensor

Compare the resistance reading between terminals of the in-car temperature sensor with specifications shown in the following graph: should be within specification.




CAUTION: The sensor uses a thermistor which can be damaged if high current is applied to it during testing. Therefore, use a circuit tester with a measuring current of 1 mA or less.



Ambient Temperature Sensor

Compare the resistance reading between terminals of the ambient temperature sensor with specifications shown in the following graph: should be within specification.



CAUTION: The sensor uses a thermistor which can be damaged if high current is applied to it during testing. Therefore, use a circuit tester with a measuring current of 1 mA or less.

