

Airbag Assembly


Removal

⚠ WARNING Store a removed airbag assembly with the pad surface up, if the airbag is improperly stored face down, accidental deployment could propel the unit with enough force to cause serious injury.


CAUTION :

- Do not install used SRS parts from another car. When repairing, use only new SRS parts.
- Carefully inspect the airbag assembly before installing. Do not install an airbag assembly that shows signs of being dropped or improperly handled, such as dents, cracks or deformation.
- Always keep the short connector on the airbag connector when the harness is disconnected.
- Do not disassemble or tamper with the airbag assembly.

1. Disconnect both the negative cable and positive cable from the battery.
2. Remove maintenance lid A below the airbag, then remove the short connector.



3. Disconnect the connector between the airbag and cable reel.
4. Connect the short connector to the airbag side of the connector.



5. Remove maintenance lid B and the cruise control set/resume switch cover. Insert a TORX® T30 bit and remove the two TORX® bolts, then remove the airbag assembly.

