



### 8. Manual Transmission

Number	Tool Number	Description	Q'ty	Remarks
①	07GAD-PG20100	Pin Driver, 5.0 mm	1	
②	07GAD-PG40100	Oil Seal Driver	1	
③	07GAJ-PG20101	Mainshaft Thrust Clearance Inspection Tool	1	
④	07GAJ-PG20200	Preload Inspection Tool	1	
⑤	07744-0010400	Pin Driver, 5.0 mm	1	07944-6110100 may also be used.
⑥	07746-0010300	Attachment, 42 x 47 mm	1	
⑦	07746-0010500	Attachment, 62 x 68 mm	1	07947-6340200 may also be used.
⑧	07746-0030100	Driver	1	
⑨	07749-0010000	Driver	1	07949-6110000 may also be used.
⑩	07936-6340000	Bearing Remover Set	1	
⑪	07936-6890101	Bearing Puller Attachment	1	Use changed to 07936-6340000 attachment.
⑫	07979-PJ40000	Mainshaft Stand Base	1	

### 9. Automatic Transmission

Number	Tool Number	Description	Q'ty	Remarks
①	07GAB-PF50100	Mainshaft Holder	1	
②	07GAC-PF40210	Bearing Remover Attachment	1	Use changed to 07936-6340000 attachment.
③	07GAC-PG40101	Housing Puller	1	07HAC-PK40100 may also be used.
④	07GAD-PG20100	Pin Driver, 5.0 mm	1	
⑤	07GAD-PG40100	Oil Seal Driver	1	
⑥	07GAE-PG40001	Clutch Spring Compressor Set	1	
⑦	07GAE-PG40200	Compressor Bolt Assembly	1	
⑧	07HAE-PL50100	Compressor Attachment	1	
⑨	07HAF-PL50100	Gear Installer	1	
⑩	07406-0020003	Oil Pressure Gauge Set	1	
⑪	07406-0020201	Oil Pressure Gauge Hose	(3)	Component Tool
⑪-1	07746-0010500	Attachment, 62 x 68 mm	1	
⑫	07746-0030100	Driver	1	
⑬	07749-0010000	Driver	1	07949-6110000 may also be used.
⑭	07936-6340000	Bearing/Transmission Case Puller	1	
⑮	07947-6340201	Driver Attachment, E	1	
⑯	07947-6340500	Driver Attachment, E	1	
⑰	07960-6120100	Compressor Attachment	1	

### 10. Driveshafts

Number	Tool Number	Description	Q'ty	Remarks
①	07746-0010400	Attachment, 52 x 55 mm	1	
②	07746-0010500	Attachment, 62 x 68 mm	1	
③	07746-0040900	Pilot, 40 mm	1	
④	07749-0010000	Driver	1	
⑤	07947-SD90200	Oil Seal Driver	1	
⑥	07947-6340201	Attachment	1	
⑦	07965-SD90100	Support Base	1	
⑧	07965-SD90200	Support Collar	1	