


Idle Control System

Troubleshooting Flow Chart — A/T Shift Position Signal

This signals the PGM-FI ECU when the transmission is in Neutral or Park.


Inspection of A/T Shift Position Signal





(To page 6-69)



(From page 6-68)



Measure voltage between B7 (+) terminal and A18 (-) terminal in Park position.



A/T shift position signal is OK.