


Engine Tune-up

Oil Filter Replacement

WARNING Loosen the oil filter carefully while the engine is hot, the hot oil may cause scalding.

CAUTION: Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.

1. Remove the oil filter with the special oil filter socket.




OIL FILTER SOCKET
07912-6110001

Torque: One turn
(22 N·m (2.2 kg-m, 16 lb-ft))

2. Inspect the threads and rubber seal on the new filter. Wipe off seat on oil filter base, then apply a light coat of oil to the rubber seal, and install filter.
3. After the rubber seal is seated, tighten the filter by turning approximately one turn.

NOTE: Use only filters with a built-in bypass system.

Torque: One turn (22 N·m (2.2 kg-m, 16 lb-ft))



4. Start the engine and check the filter for oil leakage.