

S4 Switch

Test

- 1. Remove the center console.
- 2. Disconnect the switch connector and remove the S4 switch.
- 3. Check for continuity between the terminals by pressing and releasing the switch button according to the table below.

TERMINAL	B	A	C	D		E
POSITION						
PRESS	○	○		○	○	○
RELEASE		○		○	○	○

