


Front Bumper

Replacement

1. Remove the screw, then remove the ambient sensor and clip.
2. Remove the front side turn signal lights, then disconnect the wire harness.
3. Remove the 7 bumper lower mount bolts and the 4 bumper mount bolts.
4. Remove the bumper by sliding it forward.

If necessary:

5. Remove the bolts and nuts, then remove the front spoiler.
6. Remove the bumper brackets by removing the bracket mount bolts.
7. Remove the screws, then remove the mud guards.



8. Installation sequence is essentially the reverse order of removal.