

Maintenance Schedule

ITEMS	Service at the interval of listed x 1,000 km (miles) or after that number of months, whichever comes first.					R—Replace I—Inspect After inspection, clean, adjust, repair or replace if necessary				
	x 1,000 km	20	40	60	80	100				
	x 1,000 miles	12	24	36	48	60				
	months	12	24	36	48	60				
Idle speed and idle CO *5		I	I	I	I	I				
Idle speed and idle CO *6							I			
■ Engine oil and oil filter	Replace every 10,000 km (6,000 miles) or 6 months									
■ Transmission oil			R			R				
■ Radiator coolant						R*1				
Cooling system, hoses and connections			I			I				
E.G.R. system *4							I			
E.G.R. system *2					I		I			
E.G.R. filter *2							R			
Secondary air supply system *4							I			
Air cleaner element *7			R			R				
Air cleaner element *8		R	R	R	R	R	R			
Fuel filter			R			R				
Tank, fuel line and connections			I			I				
Evaporative emission control system *3							I			
Ignition timing and control system *5			I			I				
Ignition timing and control system *6							I			
Spark plugs *2		R	R	R	R	R	R			
Spark plugs *9				R*10		R*10				
Distributor cap and rotor *5			I			I				
Distributor cap and rotor *6							I			
Ignition wiring *5			I			I				
Ignition wiring *6							I			
Positive crankcase ventilation valve *5			I			I				
Positive crankcase ventilation valve *6							I			
Brake hoses, lines (Including ALB hoses and pipes for ALB models)		I	I	I	I	I	I			
Brake fluid (Including ALB fluid for ALB models)			R			R				
Front brake discs and calipers		I	I	I	I	I	I			
Front brake pads	Inspect every 10,000 km (6,000 miles) or 6 months									
Rear brake discs, calipers and pads			I			I				
Parking brake		I	I			I				

■ **REMARK:** These service intervals assume routine checking and replenishment has been done, as needed, by the customer.



Service at the interval of listed x 1,000 km (miles) or after that number of months, whichever comes first.	R—Replace I—Inspect After inspection, clean, adjust, repair or replace if necessary					
	x 1,000 km	20	40	60	80	100
	x 1,000 miles	12	24	36	48	60
ITEMS	months	12	24	36	48	60
Exhaust pipe and muffler		I	I	I	I	I
Suspension mounting bolts		I	I	I	I	I
Front wheel alignment		I	I	I	I	I
Steering operation, tie rod ends, steering gear box and boots		I	I		I	
ALB high pressure hose* ⁹					R	
ALB operation* ⁹		I	I		I	
Power steering system		I	I	I	I	I
Power steering pump belt			I		I	
Catalytic converter heat shield (with catalytic converter)						I

*¹ Thereafter, replace every 2 years or 40,000 km (24,000 miles), whichever comes first.

*² Only for cars using leaded gasoline

*³ Only for cars using unleaded gasoline and KY type

*⁴ Only for cars using unleaded gasoline except KQ

*⁵ Except for KS and KX

*⁶ For KS and KX

*⁷ For European and KQ type

*⁸ Except for European and KQ type

*⁹ Only for cars using unleaded gasoline.

*¹⁰ For KS type, replace every 2 years or 40,000 km (24,000 miles), whichever comes first after 30,000 km (18,000 miles).

CAUTION: The following items must be serviced more frequently on cars normally used under severe driving conditions. Refer to the chart below for the appropriate maintenance intervals.

"Severe driving conditions" include:

A: Repeated short distance driving

B: Driving in dusty conditions

C: Driving in severe cold weather

D: Driving in areas using road salt or other corrosive materials

E: Driving on rough and/or muddy roads

F: Towing a trailer

R—Replace

I—Inspect. After inspection, clean, adjust, repair or replace if necessary.

Condition	Maintenance item	Maintenance operation	Interval
A B • • • F	Engine oil and oil filter	R	Every 5,000 km (3,000 miles) or 3 months
• • • • • F	Transmission oil	R	Every 20,000 km (12,000 miles) or 12 months
A B • D E F	Front brake discs and calipers	I	Every 10,000 km (6,000 miles) or 6 months
A B • D E F	Rear brake discs, calipers and pads	I	Every 20,000 km (12,000 miles) or 12 months
• B C • E •	Power steering system	I	Every 10,000 km (6,000 miles) or 6 months

CAUTION: Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.