





Clock

Removal

1. Remove the 4 screws and the center dash compartment from the dashboard.
2. Remove the 2 screws from both sides of the clock, then disconnect the 6-P connector from the clock.



Terminals



Terminal	Wire	Destination
A	WHT/YEL	Memory power (hot at all time)
B	YEL	Switched power (hot with key on)
C	RED/BLK	Light-on signal
D	BLK	Ground