

Brake Hoses/Pipes


Inspection/Connections



1. Inspect the brake hoses for damage, leaks, interference or twisting.
2. Check the brake lines for damage, rusting or leakage. Also check for bent brake lines.
3. Check for leaks at hose and line joints or connections, and retighten if necessary.

CAUTION: Replace the brake hose clip whenever the brake hose is serviced.

NOTE: LH Drive shown, RH Drive is similar.



(cont'd)

Brake Hoses/Pipes

Inspection/Connections (cont'd)

CAUTION:

- The brake pipes and modulator pipe fittings are color coded.

