

Hood

Replacement/Adjustment

1. Pull the windshield washer hose out of the hood.
2. Hold the hood up and remove the bolts from both support strut mounts.
3. Remove the hinge mounting bolts, then remove the hood.
4. When installing the hood, don't tighten the hinge bolts until you've checked adjustments shown below.

Move the strikers to the FRONT or BACK, RIGHT or LEFT as necessary to equalize the gap between the hood and the body.

