




Test


1. Test brake light switch by pushing the brake pedal.
2. If the brake lights do not go on, check the No. 31 (20 A) fuse in the under-hood relay box, and the brake light bulbs in the taillight assembly and the high mount brake light.
3. If the fuse and bulbs are OK, disconnect the 4-P connector from the brake light switch.



4. Check for continuity between the A and B terminals.
There should be continuity with the brake pedal pushed.
 - If no continuity, replace the switch or adjust pedal height.
 - If there is continuity, but the brake lights do not go on:
 - Poor ground (G501).
 - An open in the WHT/GRN or GRN/WHT wire.
 - Faulty brake light failure sensors.

High Mount Brake Light Replacement

1. Remove the 2 screw covers and screws, then remove the high mount brake light on the rear shelf.
2. Disconnect the 2-P connector from the light assembly.



3. Turn the socket 45° counterclockwise to remove the bulb.
4. Install the high mount brake light in the reverse order of removal, and clean the rear window glass before installing.