


Preparation of Work




Special Caution Items For This Car

1. The engine hood opens almost vertical during installation or removal of the engine or transmission for easy operation.
 - Remove the wiper blade.
 - Fix the engine hood in the vertical position by removing the open stay mounting bolt on the hood side and fitting it to the mounting hole nearer to the hinge.




2. ALB piping system servicing
 - Disassemble the ALB piping system after relieve the high-pressured brake fluid.
 - Otherwise, the high-pressured brake fluid will burst out and it is very dangerous.
 - See section 13 how to relieve the high-pressured brake fluid.

ALB T WRENCH
07HAA-SG00100
or 07907-SB00000




3. Fuel Line Servicing
 - Relieve fuel pressure by loosening the service bolt provided on the top of the fuel filter before disconnecting a fuel hose or a fuel pipe.

SERVICE BOLT
12 N·m (1.2 kg-m, 9 lb-ft)



- Be sure to replace washers, O-rings, and rubber seal with new ones when servicing fuel line parts.
- Always apply oil to the surfaces of O-rings and seal rings before installation. Never use brake fluid, radiator fluid, vegetable oils or alcohol-based oils.




(cont'd)

Preparation of Work

Special Caution Items For This Car (cont'd)

- When assembling the flare joint of the high-pressure fuel line, clean the joint and coat with new engine oil.
- When installing an injector, check the angle of the coupler. The center line of the coupler should align with the setting mark on the injector holder.



4. Inspection for fuel leakage

- After assembling fuel line parts, turn ON the ignition switch (do not operate the starter) so that the fuel pump is operated for approximately two seconds and the fuel is pressurized. Repeat this operation two or three times and check whether any fuel leakage has occurred in any of the various points in the fuel line.

5. Installation of an amateur radio for cars equipped with PGM-FI A/T, Cruise control and ALB.

Care has been taken for the PGM-FI A/T, Cruise control and ALB control units (computer) and its wiring to prevent erroneous operation from external interference, but erroneous operation of the computer may be caused by entry of extremely strong radio waves. Attention must be paid to the following items to prevent erroneous operation of the computer.

- The antenna and the body of the radio must be at least 200 mm (7.9 in.) away from the computer (See Section 16, Relays and Control Units Location).
- Do not lead the antenna feeder and the coaxial cable over a long distance parallel to the wiring, and when crossing with the wiring is required, execute crossing at a right angle.
- Do not install a radio with a large output (max. 10 W).

6. Apply liquid gasket to the transmission, oil pump cover, right side cover and water outlet. Use HONDA PARTS NO. 08740-99986 as a liquid gasket.

- Check that the mating surfaces are clean and dry before applying liquid gasket. Degrease the mating surfaces if necessary.
- Apply liquid gasket evenly, being careful to cover all the mating surface.
- To prevent leakage of oil, apply liquid gasket to the inner threads of the bolt holes.
- Do not allow liquid gasket to stand for more than 20 minutes before assembly.
- Fill the case with clean engine oil or coolant 30 minutes after assembly.


7. Since a V-type 6-cylinder engine is used, carefully prevent removed bolts, nuts and washers from falling into the valley between V-type cylinders around the intake manifold during maintenance.

- Putting shop towel in the gap in the V-bank valley is recommended to prevent dropping.

8. The oil filter case is removed from the engine block during engine removal and installation. If foreign matter enters the oil path, the lubrication system may clog. Be sure to fit a blind plug to the oil hole.


9. The layout of the engine and transmission is the reverse of that of conventional Honda cars. The engine is mounted on the right side, and the transmission on the left. The direction of engine revolution, therefore, is reversed. It is clockwise as viewed from the timing belt pulley.

- After timing belt adjustment, always rotate the engine clockwise as viewed from the pulley side.





10. Cylinder Nos. are No. 1, No. 2 and No. 3 from the timing belt side of the rear bank cylinders, and No. 4, No. 5 and No. 6 from the timing belt side of the front bank cylinders.




11. The hydraulic tappet has been adopted to eliminate the need for valve clearance adjustment. After disassembling the valve, head and cylinder or after maintenance of the valve train, always carry out the following operations:


- Bleed the air from the chamber when inspecting the hydraulic tappet (section 5).
- Clean each oil path in the engine. Use an air nozzle to eliminate any clogging with dirt, etc.
- Before installing the camshaft bearing caps, fill the oil path in the hydraulic tappet with engine oil from the oil filler on the cylinder head (section 5).
- After installing the camshaft, properly adjust the exhaust rocker arm adjusting screw (section 5).

CAUTION: Observe all safety precautions and notes while working.

1. Protect all painted surfaces and seats against dirt and scratches with a clean cloth or vinyl cover.



2. Work safely and give your work your undivided attention. When either the front or rear wheels are to be raised, block the remaining wheels securely. Communicate as frequently as possible when a work involves two or more workers. Do not run the engine unless the shop or working area is well ventilated.



3. Prior to removing or disassembling parts, they must be inspected carefully to isolate the cause for which service is necessary. Observe all safety notes and precautions and follow the proper procedures as described in this manual.



Mark or place all removed parts in order in a parts rack so they can be reassembled in their original places.




(cont'd)


Preparation of Work

(cont'd)


4. Use the special tool when use of such a tool is specified.




5. Parts must be assembled with the proper torque according to the maintenance standards established.
6. When tightening a series bolts or nuts, begin with the center or large diameter bolts and tighten them in crisscross pattern in two or more steps.




7. Use new packings, gaskets, O-rings and cotter pins whenever reassembling.



8. Use genuine HONDA parts and lubricants or those equivalent. When parts are to be reused, they must be inspected carefully to make sure they are not damaged or deteriorated and are in good usable condition.



9. Coat or fill parts with specified grease as specified (page 4-2). Clean all removed parts in or with solvent upon disassembly.




10. Brake fluid and hydraulic components
- When replenishing the system, use extreme care prevent dust and dirt from entering the system.
 - Do not mix different brands of fluid as they may not be compatible.
 - Do not reuse drained brake fluid.
 - Brake fluid can cause damage to painted surfaces. Wipe up spilled fluid at once.
 - After disconnecting brake hoses or pipes, be sure plug the openings to prevent loss of brake fluid.
 - Clean all disassembled parts only in clean BRAKE FLUID. Blow open all holes and passages with compressed air.



- Keep disassembled parts from air-borne dust and abrasives.
- Check that parts are clean before assembly.

11. Avoid oil or grease getting on rubber parts and tubes, unless specified.


12. Upon assembling, check every possible part for proper installation and movement or operation.






Electrical


- Before making any repairs on electric wires or parts, disconnect the battery cables from the battery starting with the negative (–) terminal.




- After making repairs, check each wire or part for proper routing and installation. Also check to see that they are connected properly.
- Always connect the battery positive (+) cable first, then connect the negative (–) cable.



- Coat the terminals with clean grease after connecting the battery cables.
- Don't forget to install the terminal cover over the positive battery terminal after connecting.
- Before installing a new fuse, isolate the cause and take corrective measures, particularly when frequent fuse failure occurs.





- Be sure to install the terminal cover over the connections after a wire or wire harness has been connected.




- When removing locking couplers, be sure to disengage the lock before disconnecting.
- Couplers may be of two types, those in which the lock is pressed to remove, and those in which the lock is pulled up to remove. Be sure to ascertain the type of locking device before beginning work. The following is a depiction of the means of disconnecting various typical couplers.


Press to disengage:



Pull up to disengage:



- When disconnecting locks, first press in the coupler tightly (to provide clearance to the locking device), then operated the tab fully and remove the coupler in the designated manner.




(cont'd)


Preparation of Work

Electrical (cont'd)


- When disconnecting a coupler, pull it off from the mating coupler by holding on both couplers.
- Never try to disconnect couplers by pulling on their wires.




- Before connecting couplers, check to see that the terminals are in place and are not bent or distorted.




- Insert couplers fully until they will no longer go.
- Some couplers have locking tabs that must be aligned and engaged securely.
- Don't use wire harnesses with a loose wire or coupler.




- Place the plastic cover over the mating coupler after reconnecting. Also check that the cover is not distorted.




- Before connecting, check each connector cover for damage. Also make sure that the female connector is tight and not loosened from the previous use.




- Insert male connectors into the female connectors fully until they will no longer go.
- Be sure that plastic cover is placed over the connection.
- Position the wires so that the open end of the cover is not facing upward.



- Secure wires and wire harnesses to the frame with their respective wire bands at the designated locations. Position the wiring in the bands so that only the insulated surfaces contact the wires or wire harnesses.




- A loose wire harness or cable can be a hazard to safety. After clamping, check each wire for security in its clamp.




- Do not squeeze wires against the weld when a weld-on clamp is used.




- After clamping, check each harness to be certain that it is not interfering with any moving or sliding parts of the vehicle.
- Keep wire harnesses away from the exhaust pipes and other hot parts.




- Always keep a safe distance between wire harnesses and any heated parts.




- Do not bring wire harnesses in direct contact with sharp edges or corners.
- Also avoid contact with the projected ends of bolts, screws and other fasteners.




- Route harnesses so they are not pulled taut or excessively slackened.




- Protect wires and harnesses with tape or a tube if they are in contact with a sharp edge or corner.




- Clean the attaching surface thoroughly if an adhesive is used. First, wipe with solvent or alcohol if necessary.




- Seat grommets in their grooves properly.



- Do not damage the insulation when connecting a wire.
- Do not use wires or harnesses with a broken insulation. Repair by wrapping with protective tape or replace with new ones if necessary.



- After installing parts, make sure that wire harnesses are not pinched.




(cont'd)


Preparation of Work

Electrical (cont'd)


- After routing, check that the wire harnesses are not twisted or kinked.



- Wire harnesses should be routed so that they are not pulled taut, slackened excessively, pinched, or interfering with adjacent or surrounding parts in all steering positions.



- When using the Service Tester, follow the manufacturer's instructions and those described in the Shop Manual.



- Do drop parts.



- Rust is the enemy of all finished surfaces. Before connecting connectors and couplers, check the terminals and remove, if any, rust using a fine sand paper or emery cloth.



Symbol Marks

The following symbols stand for:



:Apply engine oil.



:Apply brake fluid.



:Apply grease.



:Apply Automatic Transmission Fluid.



:Apply Power Steering Fluid.

①, ②, ③, --- : Sequence of removal.
①, ②, ③, ---