


Blower

Replacement

1. Disconnect the battery negative terminal.
2. Remove the screws (3), then remove the glove box lower cover.
3. Remove the screws (2), then remove the glove box.
4. Remove the screws (4) and tapping screws (5), then remove the glove box frame, clips (2), and side heater duct.
5. With automatic climate control system: Discharge the refrigerant very slowly from the climate control system (page 15-86).
6. Remove the evaporator (page 15-83) or heater duct.
7. Disconnect the wire connectors from the blower.
8. Remove the mounting bolts (3) from the blower.
9. Remove the blower.
10. Install the blower in the reverse order of removal making sure there is no air leakage.




Disassembly

NOTE:

- Before reassembly, make sure that the air door and linkage moves smoothly without binding.
- When re-attaching the actuator, make sure its positioning will not allow the air door to be pulled too far. Attach the actuator and all linkage, then apply battery voltage and watch the door movement. If necessary, loosen the holding screw and move the actuator up or down.

To adjust the control rod:

Connect the REC control motor connector to the main wire harness, push the FRESH/REC switch to "FRESH" and open the air doors. Then connect the control rod to the arm while holding the air doors open.



NOTE: LH Drive shown, RH Drive is similar.

