

# Maintenance Schedule

SERVICE AT THE INTERVAL OF LISTED KM (MILES) OR MONTHS, WHICHEVER OCCURS FIRST.						
ITEMS	x 1,000 km	20	40	60	80	100
	x 1,000 miles	12	24	36	48	60
	months	12	24	36	48	60
IDLE SPEED AND IDLE CO		I	I	I	I	I
ALTERNATOR DRIVE BELT					I	
■ ENGINE OIL AND OIL FILTER		Replace every 10,000 km (6,000 miles) or 6 months				
■ TRANSMISSION OIL			R		R	
■ RADIATOR COOLANT					R*1	
COOLING SYSTEM, HOSES AND CONNECTIONS			I		I	
E.G.R. SYSTEM*4						I
E.G.R. SYSTEM*2				I		I
E.G.R. FILTER*2						R
SECONDARY AIR SUPPLY SYSTEM*4						I
AIR CLEANER ELEMENT			R		R	
FUEL FILTER			R		R	
TANK, FUEL LINE AND CONNECTIONS			I		I	
EVAPORATIVE EMISSION CONTROL SYSTEM*3						I
IGNITION TIMING AND CONTROL SYSTEM			I		I	
SPARK PLUGS*2		R	R	R	R	R
SPARK PLUGS*3			R		R	
DISTRIBUTOR CAP AND ROTOR			I		I	
IGNITION WIRING			I		I	
CRANKCASE EMISSION CONTROL SYSTEM			I		I	
BRAKE HOSES, LINES (Including ALB hoses and pipes)		I	I	I	I	I
BRAKE FLUID (Including ALB fluid)			R		R	
FRONT BRAKE DISCS AND CALIPERS		I	I	I	I	I
FRONT BRAKE PADS		Inspect every 10,000 km (6,000 miles) or 6 months				
REAR BRAKE, DISCS, CALIPERS AND PADS			I		I	
PARKING BRAKE		I	I		I	
EXHAUST PIPE AND MUFFLER		I	I	I	I	I
SUSPENSION MOUNTING BOLTS		I	I	I	I	I
FRONT WHEEL ALIGNMENT		I	I	I	I	I
STEERING OPERATION, TIE ROD ENDS, STEERING GEAR BOX AND BOOTS		I	I		I	
ALB HIGH PRESSURE HOSE					R	
ALB OPERATION		I	I		I	
POWER STEERING SYSTEM		I	I	I	I	I
POWER STEERING PUMP BELT			I		I	
CATALYTIC CONVERTER HEAT SHIELD (with catalytic converter)						I

R—Replace I—Inspect. After inspection, clean, adjust, repair or replace if necessary \*1 Thereafter, replace every 2 years or 40,000 km (24,000 miles), whichever comes first.  
 ■ REMARK: These service intervals assume routine checking and replenishment has been done, as needed, by the customer. \*2 Only for cars using leaded gasoline  
 \*3 Only for cars using unleaded gasoline  
 \*4 Only for cars unleaded gasoline

**CAUTION:** The following items must be serviced more frequently on cars normally used under severe driving conditions. Refer to the chart below for the appropriate maintenance intervals.

“Severe driving conditions” include:

- A: Repeated short distance driving
- B: Driving in dusty conditions
- C: Driving in severe, cold weather
- D: Driving in areas using road salt or other corrosive materials
- E: Driving on rough and/or muddy roads
- F: Towing a trailer

R—Replace

I—Inspect. After inspection, clean, adjust, repair or replace if necessary.

Condition	Maintenance item	Maintenance operation	Interval
A B . . . F	Engine oil and oil filter	R	Every 5,000 km (3,000 miles) or 3 months
. . . . . F	Transmission oil	R	Every 20,000 Km (12,000 miles) or 12 months
A B . D E F	Front brake discs and calipers	I	Every 10,000 km (6,000 miles) or 6 months
A B . D E F	Rear brake discs, calipers and pads	I	Every 20,000 km (12,000 miles) or 12 months
. B C . E .	Power steering system	I	Every 10,000 km (6,000 miles) or 6 months