



# Evaporator




## Replacement

1. Disconnect the battery negative terminal.
2. Discharge the refrigerant (page 15-86).
3. Disconnect the receiver line and suction hose from the evaporator.


**CAUTION:** Cap the open fittings immediately to keep moisture out of the system.



4. Remove the 5 screws, then remove the glove box lower cover and glove box.
5. Remove the 4 screws, then remove the glove box frame and side duct.
6. Disconnect the wire harness from the evaporator temperature sensor connector.



7. Remove the 4 tapping screws and 3 mounting bolts.



8. Pull the evaporator away from the body.
9. Install in the reverse order of removal, and:
  - Apply a sealant to the grommets.
  - Make sure that there is no air leakage.
10. Charge the system (page 15-87) and test performance (page 15-74).