



## Inspection



## Reassembly


1. Press the intermediate shaft bearing into the bearing support.



2. Seat the 68 mm circlip in the groove of the bearing support.

**CAUTION:** Install the circlip with the tapered end facing out.

3. Press the intermediate shaft inner seal into the bearing support.



(cont'd)