

Windshield

Broken Glass Removal

SRS wire harness is routed near the carpet.

⚠ WARNING All SRS wire harness and connectors are colored yellow. Do not use electrical test equipment on these circuit.

CAUTION: Be careful not to damage SRS wire harness when the broken glass removal.

Remove as much broken glass as possible with a vacuum cleaner.
Blow out the glass in the heater and behind the dashboard with low pressure compressed air:

⚠ WARNING Wear eye protection while using the air gun.

1. Set the temperature control dial to COLD.
2. Push the HEAT button on the function panel.
3. Make sure the recirculation button is off.
4. Blow compressed air through the defroster center vent outlet.
5. Remove the A/C evaporator and remove any glass from the air mix chamber.
6. Remove any glass from the top of the vent/defrost door.
7. Remove any glass from the top and bottom of the carpet and seats with a vacuum cleaner.

NOTE: You should remove the seats and shake them to get rid of loose remove any glass.

