

Special Tools

11. Power Steering

Number	Tool Number	Description	Q'ty	Remarks
①	07GAG—SD40000	P/S Tool Kit	1	
①-1	07GAG—SD40100	Piston Seal Ring Guide	(1)	Component Tools
①-2	07GAG—SD40200	Piston Seal Sizing Tool	(1)	
①-3	07GAG—SD40300	Cylinder End Seal Slider	(1)	
①-4	07GAG—SD40400	End Seal Guide	(1)	
①-5	07GAG—SD40600	P/S Tool Kit Case	(1)	
②	07GAK—SE00100	P/S Joint Adaptor Kit	1	Component Tools
②-1	07GAK—SE00110	P/S Joint Adaptor (Pump)	(1)	
②-2	07GAK—SE00120	P/S Joint Adaptor (Hose)	(1)	
③	07JGG—0010100	Belt Tension Gauge	1	
④	07HAJ—SD40400	Deployment Tool	1	
⑤	07KAA—SD40100	Locknut Wrench, 40 mm	1	
⑥	07406—0010101	Bypass Tube Joint	1	
⑦	07406—0010200	P/S Pressure Gauge Assembly	1	
⑦-1	07406—0010300	Pressure Control Valve	(1)	Component Tools
⑦-2	07406—0010400	Pressure Gauge	(1)	
⑧	07725—0030000	Universal Holder	1	07725—0010101 may also be used.
⑨	07746—0010300	Attachment, 42 x 47 mm	1	
⑩	07749—0010000	Driver	1	07949—6110000 may also be used.
⑪	07941—6920003	Ball Joint Remover	1	
⑫	07944—6110200	Pin Driver, 8 mm	1	07941—6920002 may also be used.
⑬	07947—6340300	Driver Attachment	1	
⑭	07953—7190000	Collar Driver	1	
⑮	07974—SA50600	Pinion Seal Guide	1	
⑯	07974—SA50800	Ball Joint Boot Clip Installation Guide	1	

12. Suspension

Number	Tool Number	Description	Q'ty	Remarks
①	07GAC—SE00100	Ball Joint Remover	1	
②	07GAE—SE00101	Shock Absorber Spring Compressor	1	07GAE—SE00100 may also be used.
③	07GAF—SE00401	Front Hub Base	1	
④	07GAF—SD40100	Hub Assembly Pin	1	
⑤	07GAF—SD40200	Hub Assembly Driver Attachment	1	
⑥	07GAF—SD40300	Ball Joint Disassembly Tool Kit	1	
⑥-1	07GAF—SD40310	Ball Joint Remover Base	(1)	Component Tools
⑥-2	07GAF—SD40320	Ball Joint Installer Base	(1)	
⑥-3	07GAF—SD40330	Ball Joint Remover/Installer	(1)	
⑦	07GAF—SD40700	Hub Dis/Assembly Base	1	
⑧	07GAG—SD40700	Ball Joint Boot Clip Installation Guide	1	
⑨	07HAD—SG00100	Bearing Driver Attachment	1	
⑩	07HGK—0010200	Wheel Alignment Gauge Attachment	1	
⑪	07746—0010500	Attachment, 62 x 68 mm	2	When servicing rear axle, 2 tools are required.
⑫	07749—0010000	Driver	1	07949—6110000 may also be used.
⑬	07941—6920003	Ball Joint Remover	1	07941—6920002 may also be used.
⑭	07965—6920201	Hub Dis/Assembly Tool B	1	
⑮	07974—SA50800	Ball Joint Boot Clip Installation Guide B	1	