


# Trunk Light and Latch Switch




## Trunk Light Replacement

1. Pry off the trunk light lens from the housing.
2. Pry off the light assembly.
3. Disconnect the 3-P connector from the housing.



From No. 3 (15 A) FUSE




To TRUNK LATCH SWITCH

## Latch Switch Test/Replacment

1. Open the trunk lid and remove the trunk lid trim panel.
2. Disconnect the connector from the trunk latch.
3. There should be continuity between the No.1 terminal and body ground.

View from wire side



4. If necessary, remove the 3 bolts to pull out the latch from the trunk lid.
5. Disconnect the lock rod from the latch.