


Fuel Filler/Trunk Opener



Replacement

1. To remove the fuel lid opener cables, remove the following parts:
 - Left side door sill molding, left half of floor mat.
 - Left quarter trim panel, and left trunk side panel.
2. Remove the screw and the release levers, then remove the opener cover. Remove the opener by removing the 2 bolts.
3. Remove the fuel lid lock by turning it 90°.



4. Remove the trunk lid inner trim panel and latch cover (page 14-62).
5. Disconnect the lock rod and wire connectors.
6. Remove the retainer, then remove the lock cylinder.
7. Remove the 7 bolts, then remove the latch, lock link and trunk lid opener solenoid all together.
8. To install, reverse the removal procedure. Check that the fuel lid opener cable is routed and connected properly.

