




Replacement

1. Remove the front console.
2. Remove the 6 screws and the center instrument panel with the stereo radio/cassette player, then disconnect the 16-P connector, the antenna lead, and the 4-P connector from the cigarette lighter.
3. Disconnect the thermofuse case from the socket end.
4. Remove the ring nut and separate the cigarette lighter socket from the thermal protector.



5. When installing the cigarette lighter, align each lug on the face panel, illumination ring and cigarette lighter socket with the slot in the hole, then position the bulb case on the thermal protector between the stoppers of the center panel.
6. Make sure that the ground wire, bulb socket and thermofuse case are seated to the cigarette lighter assembly.

Cigarette Lighter

Relay Test

1. Remove the dashboard lower panel and the cigarette lighter relay in the dash relay holder.
2. There should be continuity between the A and B terminals when the battery is connected to the C and D terminals.
There should be no continuity when the battery is disconnected.

