



Power Steering

Index

PUMP

Pump Belt Adjustment, page 11-9
Pump Pressure Check, page 11-10
Inspection, page 11-16
Pump Replacement, page 11-17
Control Valve Inspection and Replacement, page 11-18
Housing Disassembly, page 11-21
Housing Reassembly, page 11-22

GEAR BOX

Index/inspection, page 11-24
Removal, page 11-32
Overhaul, page 11-34
Installation, page 11-47

COLUMN

Removal/Installation, page 11-13

STEERING WHEEL

Disassembly/Reassembly, page 11-14

PRESSURE SWITCH

RESERVOIR

Fluid Replacement, page 11-9

SPEED SENSOR

Replacement, page 11-12

VALVE BODY UNIT

Disassembly, page 11-25
Assembly, page 11-29

