


Supplemental Restraint System (SRS)

SRS Unit Assembly Installation


CAUTION: Be sure to install the SRS wiring so that it is not pinched or interfering with other car parts.

1. Install the SRS unit.



TORX® BOLTS 6mm
10N·m(1.0kg·m, 7.2 lb·ft)
Replace.

2. Connect the connectors to the SRS unit.
NOTE: To reinstall a connector, push it into position until it clicks; then close the connector lid.
3. Install the front console.
4. Disconnect the short connector from the airbag.



5. Connect the airbag 2-P connector and cable reel 2-P connector.
6. Attach the short connector to the lid A and attach the steering wheel.
7. Connect both the negative cable and positive cable to the battery.
8. After installing the airbag assembly, confirm proper system operation:
 - Turn on the ignition to II; the instrument panel SRS light should go on for about 8 seconds and then go off.
 - Confirm operation of the radio/cassette player and cigarette lighter.