

## DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the diagnostic trouble code check, check the circuit listed for that code in the table below and proceed to the appropriate page.

DTC No. (See Page)	Detection Item	Trouble Area
11 (DI-570)	Actuator Motor Circuit	<ul style="list-style-type: none"> <li>• Cruise control actuator motor</li> <li>• Harness or connector between actuator motor and ECU</li> <li>• ECU</li> </ul>
12 (DI-572)	Actuator Magnetic Clutch Circuit	<ul style="list-style-type: none"> <li>• Cruise control magnetic clutch</li> <li>• Harness or connector between ECU and magnetic clutch, magnetic clutch and body ground</li> <li>• ECU</li> </ul>
14 (DI-575)	Actuator Motor Circuit	<ul style="list-style-type: none"> <li>• Cruise control actuator motor</li> <li>• Harness or connector between actuator motor and ECU</li> <li>• ECU</li> </ul>
15 (DI-570)	Actuator Motor Circuit	<ul style="list-style-type: none"> <li>• Cruise control actuator motor</li> <li>• Harness or connector between actuator motor and ECU</li> <li>• ECU</li> </ul>
21 (DI-577)	Vehicle Speed Sensor Circuit	<ul style="list-style-type: none"> <li>• Vehicle speed sensor</li> <li>• ECM</li> <li>• Combination meter</li> <li>• Harness or connector between vehicle speed sensor and ECM, ECM and combination meter, combination meter and ECU</li> <li>• ECU</li> </ul>
23 (DI-580)	Vehicle Speed Sensor Circuit	<ul style="list-style-type: none"> <li>• Vehicle speed sensor</li> <li>• Harness or connector ( SPD)</li> <li>• ECU</li> </ul>
32 (DI-581)	Control Switch Circuit (Cruise Control Switch)	<ul style="list-style-type: none"> <li>• Cruise control switch</li> <li>• Harness or connector between control switch and ECU</li> <li>• ECU</li> </ul>
41	Cruise Control ECU	<ul style="list-style-type: none"> <li>• Cruise control ECU</li> </ul>
42	Source voltage drop	<ul style="list-style-type: none"> <li>• Power source</li> </ul>