


## REMOVAL

### 1. REMOVE THESE PARTS:

- (a) Glove compartment door
  - (b) Glove compartment door reinforcement
  - (c) Lower No.2 finish panel
  - (d) No.4 heater to register duct
  - (e) Front door scuff plate RH
  - (f) Cowl side trim RH
  - (g) Cooling unit
- (See page [AC-25](#))



### 2. REMOVE BLOWER UNIT

- (a) Disconnect the connector from the blower motor.
- (b) Disconnect the air inlet damper control cable from the blower motor.

#### HINT:

At the time of installation, please refer to the following item.

For installing the control cable, refer to "INSTALLATION" of "HEATER CONTROL ASSEMBLY" on page [AC-93](#).

- (c) Remove the nut, bolt and blower unit.