

HEATER CONTROL ASSEMBLY

AC094-01

ON-VEHICLE INSPECTION

INSPECT HEATER CONTROL LEVER AND DIALS OPERATION

Move the control lever and dials left and right check for stiffness and binding the full range of the lever and dials.